

**Toyota OEM Center Diff Lock Switch**  
Fits 1993-1997 Toyota Land Cruisers

Qty	Part Included	Tools Needed
1	Center Diff Lock Switch	Small Flat Blade Screwdriver
		Phillips Head Screwdriver

**Thank you for purchasing Slee Off-Road parts for your Land Cruiser. All attempts have been made to supply the bracket and related parts in perfect condition with complete installation hardware. However should you have any problems with the condition of the parts or find any parts missing, please do not hesitate to contact us at 1888 4X4 SLEE or [sales@sleeffroad.com](mailto:sales@sleeffroad.com)**

Your Slee Off-Road parts are guaranteed free of defect in material and workmanship for a period of one year from date of purchase. Should you experience any problems, please contact us directly to resolve any issues. We have attempted to provide complete installation instructions provided below. However from time to time changes might be made to parts and associated hardware and you might notice small inconsistencies with the instructions. Please notify us of such occurrences so we can correct them.

**Installation Instructions (1993-1997)**

**Removal of dashboard trim piece (1993-94 models)**

1. Remove ashtray
2. Remove the two screws on either side of the ashtray sliders as well as the one about 2" inside the opening, on the top of the metal plate. Be careful not to drop it.
3. Remove the screw located under and to the left of the 3 switches along the bottom piece of the dash. (RHD Models)
4. Lower the steering column
5. Now place one hand at the ashtray opening and the other on the upright between the stereo and heater controls and pull gently. You should now have enough access in behind the dash to find the plug required.

**Removal of dashboard trim piece (1995-97 models)**

1. If your vehicle is fitted with a cup holder, remove the it by opening the cup holder and remove the two screws. If you don't have a cup holder, proceed to step 2.
2. Insert a small flat blade screwdriver under the locking tabs located on the top edge of the little "cubby hole" that is located above the radio.
3. Bend the tab down and pull out gently.
4. Repeat with other tab. Once both tabs are released the trim piece will pull out.
5. Remove the two Phillips head screws on either side of the opening.
6. Remove the ashtray.
7. Remove the two screws on either side of the ashtray opening and remove the metal bracket.
8. Grab hold of the center 'ribs' of the trim piece and pull gently. The trim piece should come off. It is attached with push in plugs. It does require some force but don't jerk it off, since you might damage the trim piece or some of the connections.

**Installation of center diff lock switch (1993-97)**

1. Remove one of the blank switch templates and insert the switch by pushing into the hole.

2. The most common location for the switch is the left most position on the top row of switches.
3. Locate the unused terminator on the wiring harness. This might require some digging. It can be located behind the radio or above the A/C controls.
4. To identify it, it will be a white female plug with a terminating male plug inserted into it. It might be wrapped in foam with a green/silver jumper wire on it.
5. Remove the terminating plug and feed the connector end through the top slot on the dash and then connect to the switch you installed.
6. Re-install the trim piece in the reverse order of removing.
7. To use the Center Diff simply press the switch, the ABS and center Diff lights should light up on the dash.



**Diff lock switch harness with terminating plug still installed**